

HONEYCOMB
Bravo Throttle
Zibo Mod 737 Profile

Content


I.a) Bravo 3

I.a) Bravo



1. Heading Select
2. Vertical Navigation (VNAV)
3. Lateral Navigation (LNAV)
4. Localizer Hold
5. Approach Hold
6. Vertical Speed button
7. Speed Hold
8. Autopilot 1 (CMD A)
9. Increase MCP ALT/VS/HDG/CRS/IAS
10. Decrease MCP ALT/VS/HDG/CRS/IAS
11. Parking Brake On
12. Parking Brake Off
13. MCP IAS (Speed)
14. MCP Left CRS (Course)
15. MCP HDG (Heading)
16. MCP VS (Vertical Speed)

17. MCP ALT (Altitude)
18. Gear Up
19. Gear Down
20. Seat Belt Sign Off
21. Seat Belt Sign On
22. Autothrottle Arm Switch On
23. Autothrottle Arm Switch Off
24. Engine 1 Start Lever Run
25. Engine 1 Start Lever Cutoff
26. Engine 2 Start Lever Run
27. Engine 2 Start Lever Cutoff
28. Wing Anti-Ice Off
29. Wing Anti-Ice On
30. Left Engine Anti-Ice Off
31. Left Engine Anti-Ice On
32. Right Engine Anti-Ice Off
33. Right Engine Anti-Ice On



1. Axis – Assignable in Simulator
2. Axis - Assignable in Simulator
3. Axis - Assignable in Simulator
4. Axis - Assignable in Simulator
5. Axis - Assignable in Simulator
6. Axis - Assignable in Simulator
7. Engine 1 Idle Reverse (Linked to throttle axis, once reversers are engaged, move throttle forward to increase reverse power)
8. Engine 2 Idle Reverse (Linked to throttle axis, once reversers are engaged, move throttle forward to increase reverse power)
9. Elevator Trim Down
10. Elevator Trim Up
11. Button - Not Used
12. Button - Not Used
13. Button - Not Used
14. Button - Not Used
15. Button - Not Used
16. Throttle 1/2 TOGA
17. Button - Not Used